

Laminate Cleaner



1 PRODUCT DESCRIPTION

Mild neutral cleaning agent for the initial and regular cleaning of laminate floors. Removes dirt, fat, grease and shoe marks. Does not leave a residue. For EN 13329-defined laminate floor coverings and laminate surfaces (including kitchen and bathroom furniture). Specifically developed for all click-laminate floors.

- Special formula neutralises unpleasant odours (e.g. cigarette smoke) and ensures better indoor air if used regularly.
- Better edge protection.
- Recommended in the EPLF (European Producers of Laminate Flooring) publication concerning the cleaning and maintenance of laminate floorings.

2 AREAS OF APPLICATION

All kinds of laminated floors and surfaces (e.g. furniture in kitchen and bathroom).

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

3 APPLICATION

Dilute Laminate Cleaner in a ratio of 1:200 (50 ml to 10 l of water) and lightly damp wipe over the floor with this solution. For larger surface areas use a dilution up 1:200 to 1:400 using the spray-cleaning method in combination with a monodisc machine such as the SRP 1 plus a white or red pad. Glue residues and stubborn stains can be removed with Elatex Universal Stain Remover.

Note: Laminated floors or surfaces should never be damp or wet for a longer period of time. Especially the edges could swell up and change shape. Therefore always wipe with thoroughly wrung-out cloths and ensure that no "pools" are created on the floor.

4 CONSUMPTION

1 l = 1000 m²

5 STORAGE

Laminate Cleaner should be stored in a cool, dry place in its closed original container. Protect from frost. Keep locked up and out of the reach of children.

6 TECHNICAL DATA

Data on ingredients (EC recommendation): less than 5% anionic surfactants, non-ionic surfactants. Contains BENZISOTHIAZOLINONE, METHYLISOTHIAZOLINONE, perfume, CITRAL, LIMONENE, LINALOOL, solvents.

Product code for cleaning and care products (Giscode): GU 50

pH: approx. 7.5 (concentrate)

ADR/RID: not a dangerous good as defined by transport regulations.

CLP: The product is not classified according to the CLP regulation.

Laminate Cleaner



EUH208 8 Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one [EC no. 247-500-7] and 2- methyl-2H-isothiazol-3-one [EC no. 220-239-6] (3:1). May produce an allergic reaction.

Even when using low-pollution products, the usual safety measures are to be observed. Completely emptied canisters can be disposed of in domestic waste, or taken to a recycling centre.

7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

8 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below

Dr. Schutz – We Care About Floors

Headquarter
Dr. Schutz GmbH
Holbeinstraße 17
D-53175 Bonn
Tel.: +49 (0)228 / 95 35 2-40
Fax: +49 (0)228 / 95 35 2-46
E-Mail: export@dr-schutz.com
www.dr-schutz.com

UK
Dr. Schutz U.K Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP

Contact: Richard Nelson
Tel.: +44 (0)1296 437827
Fax: +44 (0)1296 334219
E-Mail: richard@dr-schutz.com

Ireland
Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork

Contact: Paul O'Reardon
Mobile: 0877678388
E-Mail: drschutzireland@gmail.com

North America
Schutz NA
4701 Bath St 46
Philadelphia, PA 19137
USA

Contact: Sam Jamison
Tel.: +1(877) 272- 4889
Mobile: +1(215) 510- 7874
E-Mail: sam@schutzNA.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.